

Power brake System assembly

ZC-DL02A



- Double Circuit Brakes on panel should be operated manually
- A wall panel representing a double circuit braking system.
- As in real conditions, it should be operated by a hydraulic pump connected to the disc brake and a drum brake.
- A braking adjuster should be placed between the pump and the (rear) drum brake in the circuit in order to avoid the rear wheels locking during the braking phase.
- The same devices used in the circuit should have been sectioned and added in the panel to clearly show their operation.